



# Installation recommendation

## Design-Boden GreenTec



<b>Parquet adhesive</b>	<b>Bakit ESP / Bakit PU-P / Bakit EK neu</b>	Trowel size: TKB B11 / B 15
<b>Primer</b>	Okamul PU-V schnell (fast set)	
<b>Substrate</b>	must be ready for installation according to TOB, Part C, DIN 18365	

Follow all the requirements as per VOB, Part C, DIN 18365. However, it should be noted, that the additional Egger company specific installation instructions for substate preparation, product handling and installations are mandatory to be followed and executed.

Before and during the installation, all the necessary guidelines and information specified in the technical data sheets and on the packaging or individual units must be fully observed.

Current publication of this installation recommendation (as of April 29, 2020) all the installation recommendations that were previously listed.