

# SURFACE CATEGORY: FLOORING

## INSTALLATION RECOMMENDATION 1

### EGGER Design-Boden GreenTec

as per 10.11.2021

Parquet adhesive	Bakit ESP / Bakit PU-P / Bakit EK neu	Trowel size: TKB B11 / B 15
Primer	Okamul PU-V schnell (fast set)	
Substrate	must be ready for installation according to VOB, Part C, DIN 18365	

**Important information:**

Follow all the requirements as per VOB, Part C, DIN 18365. However, it should be noted, that the additional Egger company specific installation instructions for substrate preparation, product handling and installations are mandatory to be followed and executed.

Before and during the installation, all the necessary guidelines and information specified in the technical data sheets and the packaging or individual units must be fully observed. With the publication of this installation recommendation (as of 10.11.2021), the previously valid installation recommendations lose their validity.

**Manfred Dreher**  
Technical Manager  
Flooring/Parquet  
dreher@kiesel.com  
+49 711 93134-353

**Thomas Schaffer**  
Application Engineering  
Flooring/Parquet  
schaffer@kiesel.com  
+49 711 93134-354

**Friedrich Weber**  
Application Engineering  
Tiles, Flooring/Parquet  
weber@kiesel.com  
+49 711 93134-325

**Konrad John**  
Application Engineering in Tangermünde  
Flooring/Parquet  
john@kiesel.com  
+49 39322 95112

Kiesel Bauchemie GmbH u. Co. KG  
Wolf-Hirth-Strasse 2 · 73730 Esslingen  
Tel. +49 711 93134-0 · Fax +49 711 93134-140  
www.kiesel.com · kiesel@kiesel.com




# SURFACE CATEGORY: FLOORING

## INSTALLATION RECOMMENDATION 2

### EGGER Design-Boden GreenTec

as per 10.11.2021

Parquet adhesive	Bakit ESP / Bakit EK neu	Trowel Size: TKB B11 / B 15
Renovation system		
Adhesive	Okalift SuperChange Adhesive	Trowel size: TKB B6
Primer	where required use Okatmos® EG 20 (Mixing ratio 1:1 diluted with water)	
Substrate	must be ready for installation according to VOB, Part C, DIN 18365	

#### Important information:

Follow all the requirements as per VOB, Part C, DIN 18365. However, it should be noted, that the additional Egger company specific installation instructions for substrate preparation, product handling and installations are mandatory to be followed and executed.

Before and during the installation, all the necessary guidelines and information specified in the technical data sheets and the packaging or individual units must be fully observed.

With the publication of this installation recommendation (as of 10.11.2021), the previously valid installation recommendations lose their validity.

**Manfred Dreher**  
Technical Manager  
Flooring/Parquet  
dreher@kiesel.com  
+49 711 93134-353

**Thomas Schaffer**  
Application Engineering  
Flooring/Parquet  
schaffer@kiesel.com  
+49 711 93134-354

**Friedrich Weber**  
Application Engineering  
Tiles, Flooring/Parquet  
weber@kiesel.com  
+49 711 93134-325

**Konrad John**  
Application Engineering in Tangermünde  
Flooring/Parquet  
john@kiesel.com  
+49 39322 95112

Kiesel Bauchemie GmbH u. Co. KG  
Wolf-Hirth-Strasse 2 · 73730 Esslingen  
Tel. +49 711 93134-0 · Fax +49 711 93134-140  
www.kiesel.com · kiesel@kiesel.com

