

Quality management ISO 9001

Coding: TM001USEN

Revision: 01

Approved: 23.02.2021

Page: 1 of 2

Adhesives

for the full-surface glueing of EGGER Laminate Flooring Aqua+



Approved adhesives for the full-surface glueing of EGGER Laminate Flooring Aqua+

Adhesive producer	Adhesive (product designation)	Trowel notch for adhesive bed	Contact
DriTac	7700 EASY CLEAN	according to the technical datasheet from DriTac (www.dritac.com)	+1(973) 614-9000 info@dritac.com
	7800 SUPREME GREEN		
Taylor	2071 TUFF LOK X-LINK WOOD FLOORING Adhesive	according to the technical datasheet from Taylor (www.wftaylor.com)	800-868-4583 info@wftaylor.com
Sika	Schönox Protect	according to the technical datasheet from HPS North America, Inc (www.hpsubfloors.com)	256.246.0345 info@hpsubfloors.com
Bostik	to come		
Bona	Bona R851	according to technical datasheet from Bona (www.us.bona.com)	800-872-5515 ustech@bona.com
Mapei	to come		

The above mentioned adhesives are approved on the basis of comprehensive trials and tests performed by adhesive manufacturers. It's recommended to choose / use a low-emission adhesive (i.e. EMICODE EC1).

As a general rule:

- Full-surface bonding should be carried out by a specialist (professional floor fitter) and an adhesive approved by the adhesive manufacturer (as listed above) must be used.
- All specifications provided by the adhesive manufacturer, for example substrate preparation, trowel serration, fitting and setting times, must be observed. The adhesive must be applied on the entire surface with the stipulated trowel notch. In the case of failure to comply, all warranties will become void.
- Faulty placement in the adhesive bed must be avoided, if the evenness of the substrate as required for installation is not achieved, a system-specific base coat and / or filling must be applied without fail.
- Depending on the subfloor, the notched trowel must be replaced by a new one every 320 to 540 sq ft (30 - 50 m²) at the very most.
- EGGER Flooring International GmbH & Co. KG is not liable for the correct use and processing of the adhesive system.
- In addition, the installation instruction for EGGER Laminate Flooring Aqua+ must be observed in their entirety.

Storage of adhesives

When storing adhesives, please make sure they are not exposed to weather conditions. All specifications provided by the adhesive manufacturer, for example temperature conditions and air humidity, must be observed.

Additional documents

- Technical data sheets of the listed adhesives
- Installation instructions: EGGER Laminate Flooring Aqua+

Drying / Cure time adhesives

The drying and hardening time of the respective adhesive must be observed without fail, before the installed Aqua+ Laminate Flooring surface is approved for use.

Adhesive producer	Adhesive (product designation)	Walking on / using the floor at the earliest after	Exposure to higher loads
DriTac	7700 EASY CLEAN	8-12 hours (light traffic is allowed)	-
	7800 SUPREME GREEN	8-12 hours (light traffic is allowed)	-
Taylor	2071 TUFF LOK X-LINK WOOD FLOORING Adhesive	24 hours (light traffic is allowed)	72 hours
Sika	Schönox Protect	24 hours	-
Bostik	to come		
Bona	Bona R851	8-10 hours (light foot traffic)	12-24 hours (furniture, fixtures)
Mapei	to come		

Provisional note:

These technical leaflet is prepared based on the best available information and with due diligence. The information provided is based on practical experience, in-house testing and reflects our current level of knowledge. It is intended for information only and does not constitute a guarantee in terms of product properties or suitability for specific applications. We accept no liability for any mistakes, errors in standards, or printing errors. In addition, technical changes may result from the further development of EGGER flooring as well as changes to standards and regulations. For these reasons, EGGER Flooring International GmbH & Co. KG makes no representation or warranty related to these instructions. Our General Conditions of Sale and Incoterms apply.