

Approved adhesives for wall bonding

EGGER Laminate flooring Aqua+ and Design flooring GreenTec

As a rule, the following applies:

- As part of his duty of inspection and due diligence, the installer must ensure that the wall construction has the required stability and readiness (dust-free, dry and solid) before installation.
- Installation may only be carried out indoors.
- The construction must be carried out in accordance with the valid EGGER installation instructions (see www.egger.com) and the processing instructions of the adhesive manufacturer.
- An adhesive approved by the adhesive manufacturer must be used. All specifications provided by the adhesive manufacturer, for example trowel serration, fitting and setting times, must be observed.
- Faulty placement in the adhesive must be avoided.
- EGGER Holzwerkstoffe Wismar GmbH & Co. KG is not liable for the correct use and processing of the adhesive system.

Approved adhesives

Adhesive manufacturer	EGGER Laminate Flooring Aqua+	EGGER Design Flooring GreenTec
Soudal	Fix All Floor and Wall SMX-30 PLUS	
Bostik	WOOD H944 XTREM Ardaflex Multi	WOOD H944 XTREM
Uzin		UZIN KE 68T
Stauf	PUK 446	PUK 446

Provisional note:

This technical data sheet has been carefully drawn up to the best of our knowledge. It is intended for information only and does not constitute a guarantee in terms of product properties or its suitability for specific applications. It is based on practical experience, our own tests and corresponds to our most up-to-date knowledge. We accept no liability for any mistakes, errors in standards, or printing errors. In addition, technical changes may result from the further development of EGGER floor coverings as well as changes to standards and public law documents. The contents of this technical data sheet should therefore not be considered as instructions for use or as legally binding.