

# I SCHÖNOX Adhesive recommendation - EGGER Design-Boden GreenTec

## Substrate Preparation

Substrate (for example)	Mastic asphalt screed acc. to DIN EN 13813 (AS)	Cement based screed acc. to DIN EN 13813 (CT)	Calciumsulfate- or calciumsulfate flowing screed acc. to DIN EN 13813(CA/CAF)	Dry screed
Primer (for example)	SCHÖNOX SHP (not necessary if sufficient sanding)	SCHÖNOX VD		
Self levelling compound (for example)	SCHÖNOX HS 10 SCHÖNOX HS 10 F SCHÖNOX HS 50			SCHÖNOX HS 10

## Floor Covering Installation

Covering/ Collection	Adhesive	Tool/ trowel acc. TKB	Approx. consumption g/m <sup>2</sup>	Remark
EGGER PRO AQUA+ Laminatboden	SCHÖNOX® PROTECT Universal adhesive for highest loads	TKB B6 - B11	ca. 800 - 1000 g/m <sup>2</sup>	Pay attention to adequate wetting of the back of the covering Drying time: approx. 24 hours
EGGER HOME AQUA+ Laminatboden				
EGGER DESIGN-Boden Green TEC	SCHÖNOX® PARKETT 400 SCHÖNOX® PARKETT 600 waterless universal SMP adhesive with hard glue-line for parquet	TKB B3/B6	ca. 800 - 900 g/m <sup>2</sup>	
		TKB B3/B6	ca. 800 g/m <sup>2</sup>	

## Assembly recommendation for private bathrooms

SCHÖNOX® AB	SCHÖNOX® IFIX 2-component, rollable adhesive	Rolle	ca.460 g/m <sup>2</sup>
SCHÖNOX® FUGENDICHTBAND			
EGGER DESIGN-Boden Green TEC	SCHÖNOX® PARKETT 400 SCHÖNOX® PARKETT 600 waterless universal SMP adhesive with hard glue-line for parquet	TKB B3/B6	ca. 800 - 900 g/m <sup>2</sup>
		TKB B3/B6	ca. 800 g/m <sup>2</sup>

All adhesive fulfill EC1 PLUS acc. to GEV requirements, unless otherwise noted

Please follow the technical information of relevant SCHÖNOX product data sheets, the advices of the manufactures of floor covering and also according to the well-known guidelines and instructions. If in doubt please do some practical tests or call the SCHÖNOX Productservice under phone +02547/910-325. More detailed information, product data sheets or laying instructions are available under [www.schoenox.com](http://www.schoenox.com) or [www.egger.com](http://www.egger.com).