




Installation recommendation

Design-Boden GreenTec



Parquet adhesive	Bakit ESP / Bakit PU-P	Trowel size: TKB B11 / B 15
Renovation System		
Adhesive	Okalift SuperChange Adhesive	Trowel size: TKB B6
Primer	where ® be required use Okatmos® EG 20 (diluted with water 1:1 ratio)	
Substrate	must be ready for installation according to TOB, Part C, DIN 18365	

Follow all the requirements as per VOB, Part C, DIN 18365. However, it should be noted, that the additional Egger company specific installation instructions for substate preparation, product handling and installations are mandatory to be followed and executed.

Before and during the installation, all the necessary guidelines and information specified in the technical data sheets and an the packaging or individual units must be fully observed.

Current publication of this installation recommendation (as of April 29, 2020) all the installation recommendations that were previously listed.