

Processing instructions

Decorative faced boards Core boards



Table of contents

Table of contents	1
1. Product description	3
2. Safety	3
2.1. General	3
2.2. Work safety	4
2.3. Formaldehyde	4
2.4. Health hazard due to dust	4
2.5. Fire and explosion hazard	4
2.6. Melamine resins	4
3. Storage	5
3.1. General instructions	5
3.2. Conditioning	5
3.3. Horizontal storage	6
3.4. Vertical storage	6
3.5. Handling	7
4. Tool recommendations	8
5. Processing	8
5.1. Board expansion	8
5.2. Cut-outs	9

- 5.3. Edging9
- 5.4. Sealing of cut-outs/drill holes 10
- 5.5. Bonding 11
 - 5.5.1. Surface bonding of two boards..... 11
 - 5.5.2. Bonding with other materials 11
- 5.6. Screw connection 11
- 5.7. Flat screw connection..... 12
 - 5.7.1. Fixed points 13
 - 5.7.2. Sliding points 13
- 5.8. Horizontal joints and board joints 14
- 5.9. Lacquering 15
- 5.10. Fittings..... 15
- 5.11. Further processing of the raw board..... 16
- 6. Applications..... 16
 - 6.1. Wall cladding..... 16
 - 6.1.1. Substructure and rear ventilation..... 16
 - 6.1.2. visible mechanical fastening..... 17
 - 6.1.3. Concealed mechanical fastening..... 17
 - 6.1.4. Non-visible glued fastening 18
 - 6.2. Furniture doors..... 19
- 7. Recommendations for cleaning and use 20
- 8. Disposal 20



1. Product description

Eurodekor Faced Chipboards or MDF (according to EN 14322) consist of wood-based materials that are covered on both sides with impregnated decorative paper. They are used horizontally and vertically in furniture and interior design, such as for fronts, shelves, wardrobes or wall cladding.

Eurodekor Multilayer Faced Chipboards or MDF meet increased requirements for impact resistance thanks to special multi-layer construction up to 1 mm thickness. Multi-layer constructions have high bending strength and stability, and are therefore well suited for constructions with increased span widths. If desired, an additional overlay (HR) can be integrated for increased wear resistance.

Eurodekor Flammex Faced Boards are flame-retardant, faced chipboards and MDF with increased requirements for fire behaviour.

Eurospan Raw Chipboards consist of a sturdy core layer and fine outer layers. This three-layer structure offers a wide range of applications in furniture and interior design. In addition, the surface is ideal for different coatings.

Raw MDF are medium-density fibreboards that are very well suited for use in demanding furniture and interior design thanks to their high transverse tensile strength and edge stability.

Thin Raw Chipboards are extra-thin chipboards available from a thickness of 3 mm. They are characterised by their fine and light surface appearance and are suitable for use as top layers for lightweight boards, drawer bottoms, door skins or rear walls.

Thin Raw MDF are thin, medium-density fibreboards that are easy to process thanks to their homogeneous structure. Its surface is regular and fine-grained, and can be coated with laminate, lacquer, finish foil and veneer.

Eurodekor Faced Thin Chipboards or Eurodekor Faced Thin MDF are boards finished on one side with a coating and are particularly suitable as a decorative board in interior door production and for visible furniture rear walls.

2. Safety

2.1. General

The available tools, the processing instructions and the safety requirements should be known at the start of working with EGGER wood-based materials.

The boards may only be used within the scope of the technical limit values and properties. The technical properties and standard classifications of the boards are listed in the technical data sheets, which can be found on our website: www.egger.com. Usage outside these values requires separate testing of the boards.

Only use suitable machines and tools for processing the boards. In case of doubt, consult the respective machine or tool manufacturer. When using the boards, use suitable fastening materials. In case of doubt, consult the manufacturer of the fastening materials.

With regard to the temperature resistance of EGGER wood-based materials, there is a basic distinction between long-term and short-term heat exposure. Temperatures of up to 50 °C are permissible for continuous heat exposure. We expressly point out that continuous temperature exposure > 50 °C can lead to cracks in Eurodekor surfaces. When using technical equipment that emits heat, such as laptops, we recommend leaving sufficient distance between the heat source and the surface to avoid heat accumulation and to be able to dissipate the temperature accordingly.

As wood is a hygroscopic material, its properties change due to exposure to moisture and changes in ambient humidity. When using wood-based materials in areas with increased humidity or in contact with water or other liquids, appropriate precautions

should be taken, which are explained in more detail in the following document. For more detailed information on the recommended areas of application for the boards and the class of use with regard to use in dry and humid conditions, please refer to the technical data sheets on our website: www.egger.com. Particularly with raw boards, it is important to ensure that they do not come into contact with moisture.

ATTENTION! Improper handling of the products can lead to damage that affects safety. This can lead to functional impairments and health risks. It is therefore imperative to follow the manufacturer's instructions for use. Handle and process the products conscientiously and with general caution.

2.2. Work safety

As a general rule, personal protective equipment (PPE) such as gloves, safety glasses, hearing protection, dust/breathing protection and safety shoes should be worn when opening the packaging straps and during processing.

ATTENTION! The products can be heavy. They must be properly fastened during handling and processing to prevent them from falling over, tipping over or slipping. Fastening helps to prevent product damage and injury. Do not lift the products alone if they are too heavy.

ATTENTION! Always use personal protective equipment (PPE) when handling and processing the products.

2.3. Formaldehyde

Formaldehyde emission classes are directly related to the core material used. For information on the formaldehyde emission of the core material you are using, please refer to the technical data sheets of the core materials, available online: www.egger.com.

WARNING! Processing and use outside the technical properties and recommendations of the boards may increase the emission of formaldehyde and thus create health hazards. Please observe the marked emission class for the product.

2.4. Health hazard due to dust

Dust may be generated during processing. There is a risk of sensitising the skin and respiratory tract. Depending on the processing and the particle size, especially in the case of inhalation of dust, there may be further health hazards. The generation of dust must be taken into account when assessing the risks at the workplace.

Particularly in the case of machining processes (e.g. sawing, planing, milling), effective extraction must be used in accordance with the applicable occupational health and safety regulations. Suitable breathing protection has to be worn if no adequate extraction system is in place.

2.5. Fire and explosion hazard

Dust generated during processing can lead to fire and explosion hazards. Applicable safety and fire protection regulations must be observed.

2.6. Melamine resins

Only polymerised resins are used for the production of EGGER wood-based boards, which do not exhibit any hazardous properties after curing in the product as such and are harmless for the intended use of the product. In particular, free melamine as such is not contained in them in a concentration that would trigger additional information obligations, for example under Regulation (EC) No. 1907/2006 (REACH). Furthermore, EGGER wood-based panels naturally comply with the existing migration

thresholds according to Regulation (EU) No. 10/2011 on plastic materials and articles intended to come into contact with food.

3. Storage

3.1. General instructions

Wood-based materials should be stored, or processed, in a closed storage/workshop space with constant climatic conditions ($T \geq 10\text{ °C}$ and at approx. 50-60% relative humidity).

If the relative humidity permanently exceeds 60%, the plastic straps of the package should be opened. This prevents possible damage from the plastic straps to the surface or edging area of the top board due to increased thickness swelling of the boards.

Storage and processing conditions should correspond to the climate of subsequent use.

To ensure optimal flat storage, it is necessary to avoid the following negative impact on the product during transport, storage and processing:

- Storage in the immediate proximity of heating devices or other sources of heat
- Direct impact of heat radiation and direct sunlight (UV light outdoors)
- Uneven acclimatisation with increased air humidity variation
- Storage of individual boards; the stack's top and bottom boards react faster to changing environmental influences (climate) than boards inside the stacks

3.2. Conditioning

Wood-based material reacts to changes in ambient conditions with dimensional movement. For this reason, storage and processing conditions for the elements should correspond as closely as possible to the climate at the subsequent place of use. Prior to installation, wood-based materials should be conditioned for an adequate period of time at the installation location under the conditions of subsequent use. Compliance with the storage recommendations is required on construction sites as well. Wood-based materials must first be conditioned in the room climate where the processing will take place, so that the temperature of the material corresponds to the room temperature.

3.3. Horizontal storage

Stacking should be carried out on a load-bearing and level surface (see Fig. 1). Joists should have a uniform thickness and their length should correspond to the width of the board stack. The distance between the joists depends on the thickness of the boards.

Board thickness ≥ 15 mm: The distance must not be greater than 800 mm. In any case, at least 4 joists are recommended for half-format boards ($l=2800$ mm).


Board thickness < 15 mm: The distance should be less than 800 mm. As a rule of thumb, "distance = $50 \cdot$ board thickness (mm)" can be used.

To protect the board surfaces, always place the decorative tops of two boards against each other and/or use cover boards. If board stacks are subsequently fixed with steel or plastic straps, care must be taken to ensure adequate edge protection. This can be achieved with the help of special cardboard or by using protection boards. In the case of several stacks stored on top of each other, the joists must be placed in a vertical line underneath each other (see Fig. 2). Protruding boards in stacks of the same size should be avoided.



Figure 1

Right



Wrong




Figure 2

3.4. Vertical storage

Horizontal storage is always preferable to vertical storage because of its safety and better flatness. In the case of vertical storage, particular care must be taken to ensure that the boards are securely fixed. Adequate fixation can be achieved by means of closed storage racks, storerooms or shelves. The storage compartments should not exceed a width of 500 mm.

If open storage racks are used, the contact surface must have a minimum inclination of approx. 10° . In addition, only same-format boards should be stored in open storage locations (Fig. 3 and 4).

Right




Figure 3

Wrong




Figure 4

3.5. Handling

After removing the packaging and prior to processing, wood-based panels should be inspected for visible damage. As a general rule, all persons transporting and handling boards should wear personal protective equipment (PPE) such as gloves, safety shoes and suitable work clothing, given that the boards may have sharp edges. The boards must be lifted (see Fig. 5). The decor sides should never be pushed against one another or dragged over one another (see Fig. 6).

Right




Figure 5

Wrong




Figure 6

4. Tool recommendations

Detailed information regarding processing by milling, sawing and drilling can be found in the tool recommendations. These tool recommendations are based on various test series with the best machining results in cooperation with well-known tool manufacturers.

For more information, please visit www.egger.com/downloads

5. Processing

5.1. Board expansion

Notwithstanding the good dimensional stability of wood-based materials, changes in the ambient conditions can result in format changes. The orientation of the chips and fibres in the core material gives the board a production or running direction (see Fig. 7). The format changes are different in the longitudinal direction than in the transverse direction. The format changes must be taken into account in the construction.




Figure 7

For wood-based materials, a change in relative humidity of 10% (between 20% and 80%) can cause a change in board moisture of 1.6%. The greater the change in relative humidity, the more expansion can be expected. It is therefore important that the board is conditioned beforehand in the appropriate room climate to avoid greater expansion as a result of sizeable changes in board humidity. The table below shows the dimensional movement to be expected from several different humidity changes.

Rel. humidity at installation (%)*	Rel. humidity at time t (%)	Dimensional movement (mm/m)
65	85	1.6
65	30	-1.9
30	85	3.5

*At a temperature of 20 °C

Different climatic conditions in front of and behind laminated boards can also lead to warping or curvature of the board. For this reason, wall cladding with EGGER wood-based materials should always be executed with sufficient rear ventilation, which enables temperature and moisture equalisation or acclimatisation.

The production direction of boards can often only be recognised from the production dimensions. Woodgrains and directionally printed decors constitute an exception. When working with cut-to-size boards, it is important to ensure that the production direction is always matched up during installation. In view of the risk of confusion in the case of cut-to-size boards, the running direction should be marked on board leftovers.

5.2. Cut-outs

As a rule, before processing, it is important to ensure that the board is always securely in place so that no damage is caused by sawing, milling or drilling work. Especially narrow joining areas can break during machining due to improper storage. The board cut-outs must also be secured so that they cannot fall out or break in an uncontrolled manner and thus injure persons or cause other damage.




Figure 8

Rectangular cut-outs should be provided with a radius in the corners, as sharp-edged corners are detrimental to the material and lead to cracking (see Fig. 8). This is especially true for kitchen back walls, furniture bodies, shelves, etc., where increased shrinkage stress occurs due to frequent exposure to heat from drying. When using lighting (built-in spots), it must be ensured that a continuous temperature load of 50 °C is not exceeded.

For a clean, tear-free edge, the cut-out should be milled, preferably with a CNC router or a manual router. When using saws (e.g. bench circular saw), there is a risk that splinters can occur at the edging. These can vary depending on the machine, type of saw blade, saw tooth, etc. In the case of workpieces that are only visible on one side, it is possible to place the splinter that resulted from sawing on the non-visible rear side. Finishing the edges, known as “edge breaking” with sandpaper or other tools, is recommended to exclude notch cracks due to chipping and to avoid cut injuries during handling.

5.3. Edging

Depending on the intended use, wood-based materials are equipped with edging that provides the matching finish to all decorative coatings and take on a protective and design function. As part of the EGGER decor and material match, we also offer the matching edging for the decorative wood-based materials (see Fig. 9). EGGER edging is offered in various plastics such as ABS, PP, PMMA or PVC.

Edging is normally carried out with standard edging machines using hot-melt adhesive technology or with processing centres. For edge application, these are glued on, trimmed, milled and processed with draw blades and polishing mops. The manual application of edging is also possible using a gluing stand or edging press.

The edging has an adhesion primer coating on the rear side, which is necessary for perfect bonding. This coating has been optimised for use with EVA, PA, APAO and PUR hot-melt adhesives. Bonding cannot be guaranteed with white glue.



Figure 9

Like the core board, the edging material must be conditioned beforehand in the room climate where the processing will take place. Further information can be found in the data sheets or processing instructions for the edging at www.egger.com

5.4. Sealing of cut-outs/drill holes

In principle, Eurodekor used as table/worktops, fronts, etc., are reliably protected against moisture penetration by the coating. Moisture and damp can still reach the core board, however, via unprotected edges such as cut-outs, corner joints, mitres, back edges, drill holes, screw holes and fasteners. Especially in the case of horizontal surfaces, the necessary and final sealing work must always be carried out during final assembly. EGGER edges (thermoplastic edges) are used to seal visible cut edges. The best products for sealing hidden cut edges have been found to be sealing profiles and self-curing sealants, such as silicon rubber, polyurethane and acrylic (Fig. 10). When using sealants a primer also has to be applied; either one that forms a film or a cleaning primer depending on the material.




Figure 10

You must follow the manufacturer's instructions carefully when using these materials!

It is absolutely essential that you clean the areas you are sealing and to allow the manufacturer's specified venting time when using primers. Apply the sealant leaving no gaps or holes and then smooth over with water and detergent. Areas near joints should be masked off to prevent the surface from becoming dirty. Any pipes or cables must be centred so that a minimum distance of 2 to 3 mm is maintained on all sides of the feed-through. Careful sealing is also required.

5.5. Bonding

To avoid stress, only adequately conditioned wood-based materials should be bonded together and always only in the same running direction. Prior to bonding, the boards have to be sanded, free of dust, grease and dirt, and pre-treated as necessary. Bonding trials are recommended. Please observe the processing guidelines of the adhesive manufacturer.

5.5.1. Surface bonding of two boards

Surface bonding of two coated Eurodekor boards of large dimensions requires special precautions. Joints that are subject to major stress, for example due to vibrations, impacts, etc., must be reinforced by mechanical joints. Before bonding two coated boards, it is recommended to sand them first and clean any oil, grease or dust. Depending on the application, PUR adhesives or contact adhesives can be used. Following adhesives are possible:

- 2K-PUR-Adhesive 573.8 from Kleiberit
- Jowat 690.00 from Jowat

For bonding of two raw boards, dispersion adhesives can also be used, as these have an absorbent substrate compared to laminated boards. Possible adhesives are:

- Aquence KL 072 and Aquence KL 071/2 from Henkel
- PVAC adhesives from Kleiberit (e.g. 322.0 D2 surface glue)
- Jowacoll 103.10 from Jowat

It is important, however, to follow the adhesive manufacturer's instructions for all surface bonding and to consult the adhesive manufacturer. It is also advisable to carry out trial bonding.

5.5.2. Bonding with other materials

When bonding wood-based materials with other materials such as metals and plastics, it is always important to ensure that the adhesive is suitable for the bonding and does not attack the materials in question. For example, a solvent-free and silicone-free mirror adhesive should be used for bonding wood materials to a mirror. It is recommended to follow the adhesive manufacturer's instructions and to consult them if anything is unclear. The different expansion behaviour of the different materials must also be taken into account.

5.6. Screw connection

If fittings, wall end strips, etc., are fastened to wood-based material surfaces, the surface must be pre-drilled in the area of the screw connection. The drill holes should be 1 mm smaller than the screw diameter to avoid tension in the material and to be able to screw in the screws sufficiently tight. Alternatively, self-tapping screws can be used. With horizontal surfaces, we also recommend protecting the inside of the screw hole with sealant before screwing.

Joints that are subject to heavy loads, such as corner and body joints, can be strengthened by combining bonding and fasteners, shaped springs or grooves.

Note that a residual material thickness of 3 mm is taken into account for screw connections parallel to the edge or to the top or bottom of the board (see Fig. 12 and 13).




Figure 11



Figure 12




Figure 13

5.7. Flat screw connection

Flat screw connections with trough holes must have sufficient clearance to compensate for the dimensional movement resulting from temperature and humidity fluctuations. In this way, tension due to the dilation and shrinking movement resulting from changing climate conditions can be avoided. Floating points and a fixed point are implemented on the individual elements for this purpose.

When screwing two boards together using countersunk screws, it is recommended to countersink the screw holes with a countersink before screwing in the screws. This ensures that the coating of the board around the screw is not damaged. The board to be fixed should have a hole larger by 1 mm, the other should have a hole smaller by 1 mm, so that the screw can be screwed in (Fig. 13).

5.7.1. Fixed points

The fixed point serves to evenly distribute the expansion play and should be positioned as centrally as possible. The drill hole diameter is the same as the diameter of the fastener (see Fig. 14).



Figure 14



Figure 15

5.7.2. Sliding points

The drill hole diameter of the sliding points should be larger than the fastener (see Fig. 15). The drill hole should be covered by the head of the screw. The required expansion play is established based on the largest distance of the fixed point to the board edge. The floating point drill hole diameter must be increased by 2 mm for every metre of length. In any case, the screw must be positioned exactly in the centre of the drill hole. If necessary, this can be ensured by using suitable drilling jigs.

When necessary, use washers for the construction. In the figures, an EPDM sealing tape has been applied to the wooden sub-structure for protection against moisture. EPDM is very resistant to UV, ozone and other atmospheric influences.

5.8. Horizontal joints and board joints

Horizontal corner joints of EGGER wood-based materials are made by mitre cuts on circular table saws or by milling by means of CNC routers or manual routers with the aid of templates. The boards are then re-joined with various hardware or by bonding (Fig. 17 and 18). In the case of a horizontal joint, which is also exposed to humidity, please note that the parts and butt joints of the boards that are not protected by plastic edging should be sealed. Open joints or butt joints lead to moisture penetration into the board and to thickness swelling. The product EGGER Sealing (Fig. 16) – which prevents the penetration of moisture and other liquids, is resistant to cleaning agents, water, greases and oils and, is available in four different colours – is suitable for sealing the board joint. Detailed information can be found in the technical leaflet “**EGGER sealing for corner joints**”.

Alternatively, metal joining profiles can also be used (see Fig. 19). The profiles are easy to handle but visually rather disturbing as they interrupt the even surface and thus make cleaning more difficult.



Figure 16




Figure 17




Figure 18




Figure 19

5.9. Lacquering

For lacquering, it is recommended to use an EGGER board faced with painting grade paper. Painting grade is a high-quality, ready-to-paint coating that provides an excellent surface preparation for subsequent painting on MDF, Eurospan chipboard or Eurolight lightweight boards. For perfect painting of the board, you only have to make sure that the board is free of dust and grease. It is essential to follow the processing instructions of the paint manufacturer.

5.10. Fittings

The following points must be observed when placing fittings on wood-based materials:

- Handles or similar, which are screwed into the surface of the board, should be tightened as evenly as possible and not too tightly, otherwise indentations may occur in the boards (Fig. 20).
- In the case of blind holes in the board (Fig. 21), make sure that a residual thickness of 3 mm is maintained.




Figure 20




Figure 21

5.11. Further processing of the raw board

For further processing of the raw board, make sure that the board is free of dust, grease and mechanical surface damage. Pay special attention to leaked liquid substances. These are absorbed by the raw board and lead to uneven swelling of the board. Swelling on the board causes non-conforming further processing of the raw board.

A dispersion adhesive can be used for gluing laminate to the raw board. Possible adhesives are Aquence KL 072 and Aquence KL 071/2 from Henkel or PVAC adhesives from Kleiberit.

6. Applications

Thanks to their robustness and suitability for everyday use, wood-based materials are particularly well suited for use as interior wall cladding. We recommend a minimum board thickness of 8 mm for such applications. The substrate should be completely dry before applying the cladding. Always ensure sufficient rear ventilation or acclimatisation of the boards. The material may not be exposed to trapped moisture. All parts to be joined together must follow the same production direction.

6.1. Wall cladding

6.1.1. Substructure and rear ventilation

Wood-based materials must be attached to a stable, corrosion-resistant and force-fit substructure that securely supports the weight of the wall cladding and ensures ventilation behind the elements (see Fig. 22). In dry construction applications, the attachment of the substructure and the wood-based material must be anchored to the stud framing.

The selection of the fasteners has to be tailored to the substructure and the weight of the wall cladding. Different climate conditions in front of and behind the elements can lead to warping. It is therefore essential that wood-based material wall cladding installations always make provision for adequate ventilation to the rear of the boards, which allows temperature and humidity to equalise. Ventilation must be towards the room side.

If there is no rear ventilation or a rear ventilation gap < 2 cm, absorbent mineral substrates such as walls or the plaster must be pre-treated with waterproof, elastic barriers.

These barriers are generally painted on and prevent the penetration of water into the masonry, which is essential for application in a humid room.

Vertical battens generally permit air circulation. Where substructures are arranged horizontally, an appropriate construction must ensure that adequate ventilation is provided. The substructure should be vertically plumb to allow tension-free mounting full surface. Suitable substructures include vertical strips of wood, aluminium or wood-based materials.

The maximum spacing of the battens or the substructure depends on the wood-based material thickness used. It is important to ensure that air inlet and outlet areas remain unobstructed so that air circulation is not impeded. Also




Figure 22

ensure that the moisture of the surface to be panelled does not differ significantly from the moisture of the finished component.

The following are differentiated:

- visible mechanical fastening
- concealed mechanical fastening
- concealed glued fastening

6.1.2. Visible mechanical fastening

Fastening is done via screws or rivets on the substructure. A sufficient expansion play and the right positioning of floating and fixed points must be taken into account (see Fig. 14 and 15). An EPDM tape must be used for decoupling when using wood as substructure.

6.1.3. Concealed mechanical fastening

The concealed fastening of wood-based panels by hanging permits straightforward disassembly and appears more visually appealing in comparison to visible fastening methods. Removing the boards is quick and simple. Cables and pipework installed behind the elements are easy to reach. Depending on the chosen fastening system, another advantage is that the elements can be adjusted later on. Tension-free mounting of the elements is also possible. For all fastening methods that involve hanging, sufficient space must be allowed to raise and lower the elements. This air space or “hanging space” remains visible as a shadow gap.



Figure 23

Hanging by means of profile strips

For this fastening method, a groove is cut into the horizontal substructure to hold the rebate rail attached to the wall element. For ease of fitting, the tongue of the rebate rail should be thinner than the groove. The rebate rail on the wood-based panels should not extend across the entire element width, but should be interrupted to allow vertical air circulation. Rebate rails made of plywood or metal Z-profiles can be readily used. If it is not possible to securely screw thin wood-based panels, they can also

be glued.

Hanging by means of metal hardware

Systems with metal hardware are also offered for mounting wall elements (Fig. 23). The chosen system must be used according to the manufacturer’s recommendations to ensure secure installation.

6.1.4. Non-visible glued fastening

The fastening of wood-based panels can also be carried out by bonding to a substructure. The substructure system is force-locked to the wall (Fig. 24). When using wood as a substructure, it is necessary to apply a primer as a preliminary step to ensure secure adhesion and moisture decoupling.

Please observe the processing instructions of the adhesive manufacturer.




Figure 24

6.2. Furniture doors

When using wood-based materials as furniture doors (see Fig. 25), please note the following:

- The board may warp if the front and back of the door have different climatic conditions.
- The number of hinges depends on the hinge type, the dimensions as well as the weight of the door. Use the information provided by hinge manufacturers to calculate the number of hinges and the correct positioning. Suitable hinges are available from Blum, Hettich or Häfele, for example.
- Since format changes in the longitudinal direction are different from those in the transverse direction, it is advisable to always produce door leaves from the board in the same direction



Figure 25 (BLUM)

7. Recommendations for cleaning and use

As a general rule, stains and spilled substances such as tea, coffee and wine, etc., should be cleaned up immediately, as the cleaning effort increases if they are left to dry. When cleaning is necessary, mild agents should be used. Cleaning agents must not contain any abrasive components, as they may adversely affect the gloss level or scratch the surface. Since everything from light and fresh soiling to heavy and stubborn dirt caused by various substances is possible, proper cleaning is important.

The following information should be observed for daily use:



Placing burning cigarettes on Eurodekor causes surface damage.
Always use an ashtray.



In general, Eurodekor should not be used as cutting surfaces, as knife cuts leave cut marks even on resistant surfaces.
Always use a chopping board.



Placing hot cookware such as pots, pans, etc., as well as continuous heat sources such as a laptop on Eurodekor should be avoided; depending on the heat exposure, a change in gloss level or surface damage may occur. Always use heat protection.



Spilled liquids should always be cleaned up immediately, since longer exposure times of certain substances may affect the gloss level of Eurodekor. Especially in the areas around cut-outs and joints, spilled liquids should always be cleaned up quickly and thoroughly.

These recommendations apply in particular to matt surfaces in combination with dark decors, which are captivating in their look and feel, but make traces of use appear more pronounced.

For more information, please visit www.egger.com/downloads

8. Disposal

Any residues of wood-based materials that accumulate on the construction site, as well as those from demolition measures, should primarily be recycled. If this is not possible, they must be sent for energy recovery instead of being sent to landfill. For combustion, however, it should be noted that wood-based materials generate additional emissions compared to solid wood due to their ingredients such as glue, etc., which could be harmful to the environment, which is why appropriate filter systems are recommended for energy recovery.

Waste code according to European waste catalogue: 170201/030105.

The country-specific laws and regulations on disposal must always be observed.

Provisional note:

These processing instructions were prepared based on the best available information and with due diligence. We accept no liability for any mistakes, errors in standards, or printing errors. In addition, technical changes can result from the continuous further development of EGGER wood-based materials, tool technology and changes to standards and documents of public law. Therefore, the content of these processing instructions cannot serve as a legally binding base.