

# Processing instructions

## EGGER Worktops



### Get there faster

Simply click on the headings in the table of contents or the underlined internet addresses and you will be taken directly to the desired information. The  symbol at the bottom of the page will take you back to the table of contents.




### Content

Product description .....	2
Environment and health .....	4
» Emissions .....	4
» Resins .....	4
» Health hazard due to dust generation.....	4
» Fire and explosion hazard .....	4
» Recycling / Disposal .....	4
Handling with worktops .....	5
» Transport.....	5
» Storage and conditioning.....	5
» Handling .....	5
Processing .....	6
» Cutting .....	6
» Drilling .....	7
» Cut-outs.....	8
» Edging .....	10
Assembly .....	11
» Installation of sinks and hobs .....	11
» Worktop joints and corner joints .....	14
» Fastening and wall connection .....	17
» Structural water-repelling measures .....	19
Maintenance and cleaning recommendations.....	20
Additional documents / Product information.....	20

## Product description

Due to their functionality EGGER worktops are used in kitchens, bathrooms and offices, but also for shopfitting solutions and domestic furniture. Whatever they encounter on a daily basis, the surfaces will retain their high performance characteristics providing that you follow our recommendations on processing and assembly very closely. The following instructions are exemplary for a kitchen worktop. The worktop range is diverse and includes the following product options...

1. Postforming Worktops – MOD300/3
2. Square Edged Worktops – MOD100/1.5
3. Feelwood Square Edged Worktops – MOD100/1.5
4. PerfectSense Premium Square Edged Worktops Matt – MOD100/1.5
5. Compact Laminate Worktops Black/Coloured Core – MOD900/1.0



- 1 Decorative laminate
- 2 Eurospan raw chipboard
- 3 High density protective layer
- 4 Balancer
- 5 UV lacquer coating
- 6 Sealing

Figure 1: Postforming Worktops – Model 300/3




- 1 Decorative laminate
- 2 Eurospan raw chipboard
- 3 ABS edging
- 4 Balancer
- 5 UV lacquer coating

Figure 2: Square Edged Worktops – Model 100/1.5



- 1 Decorative lamination
- 2 Eurospan raw chipboard
- 3 ABS edging
- 4 Balancer

Figure 3: Feelwood Square Edged Worktops – Model 100/1.5



- 1 Protection foil
- 2 PerfectSense Premium Laminate Matt
- 3 Eurospan raw chipboard
- 4 ABS edging
- 5 Balancer
- 6 UV lacquer coating

Figure 4: PerfectSense Premium Square Edged Worktops Matt – Model 100/1.5



- 1 Decorative Compact laminate
- 2 Compact laminate core
- 3 Longitudinal edgings with bevel millings

Figure 5: Compact Laminates Black / Coloured Core – Model 90/1.0

## Environment and health

Please always use personal protective equipment (PPE) when handling and processing worktops. The following environmental and health information relates to machining and processing worktops.

### Emissions

Processing and use outside the technical properties and standard classification of the worktops can increase emissions and thus lead to health hazards. Please observe the marked emission class for the product.

### Resins

For the production of EGGER wood-based boards, we only use polymerised resins which do not exhibit any hazardous properties after curing the product and are harmless for the intended use of the product. In particular, free melamine is not contained in Laminates in a concentration that would trigger additional information obligations, for example under Regulation (EC) No. 1907/2006 (REACH). Furthermore, laminates naturally comply with the existing migration thresholds according to Regulation (EU) No. 10/2011 on plastic materials and articles intended to come into contact with food.

### Health hazard due to dust generation

Dust may be generated during machining and processing. There is a risk of sensitising the skin and respiratory tract. Depending on the processing and the particle size, especially in the case of inhalation of dust, there may be further health hazards. The generation of dust must be taken into account when assessing the risks at the workplace.

Particularly in the case of machining processes (e.g. sawing, planing, milling), effective extraction must be used in accordance with the applicable occupational health and safety regulations. Suitable breathing protection has to be worn if no adequate extraction system is in place.

### Fire and explosion hazard

Dust generated during machining and processing can lead to fire and explosion hazards. Applicable safety and fire protection regulations must be observed.

### Recycling / Disposal

Due to their high calorific value, the various worktop designs are very suitable for thermal recycling in appropriate firing systems. If the wood residues are collected by a disposal company for further recycling, they may usually contain a small amount of wood-based materials with ABS Edging. How high the proportion of ABS and other so-called impurities may be should be agreed with the disposal company. The country-specific laws and regulations on disposal must always be observed.

For further environmental and health information, please refer to the [Environmental and Health data sheet – Worktops](#).

## Handling with worktops

The following section describes transporting, storing and handling worktops. Improper handling can lead to safety-relevant damage. This can lead to functional impairments and health risks. It is therefore imperative to follow the manufacturer's instructions for use.

### Transport

The worktops are usually packaged and transported as shown – see figure 6. The packages must be transported dry and must not be exposed to the weather. In addition, the load must be secured against slipping and falling over in the case of transport by using suitable securing means (lashing straps, tensioning straps, etc.). Anti-slip mats should be used to prevent the load from slipping. When manually transporting long worktops, especially Compact Laminate Worktops, these must be carried on edge to prevent bending. The worktops must be unpacked after delivery and stored in accordance with chapter “Storage and conditioning”. This is the only way to ensure optimum conditions for further processing of the worktops.



Figure 6: Packaging unit worktops

### Storage and conditioning

Worktops must be stored in closed and dry rooms, protected from moisture. In addition, normal climatic conditions should be present in the rooms. Once the original packaging is removed, the worktop must be stored on full-surface, horizontal, straight, stable protective boards. Direct floor contact and/or exposure to sunlight must be avoided at all times. A laminated protective board (no raw chipboard) of at least the same format must be used to cover the top. Compact Laminate Worktops react to changes in ambient conditions with dimensional movement. For this reason, storage and processing conditions for the elements should correspond as closely as possible to the climate at the subsequent place of use. Prior to assembly, compact laminate elements should be conditioned for an adequate period of time at the installation location under the conditions of subsequent use. Compliance with the storage recommendations is required on construction sites as well.

### Handling

After removing the packaging and prior to processing, the worktops should be inspected for visible damage. In view of the relatively heavy weight, special care is required when transporting and handling worktops. As a rule, all persons transporting and / or handling worktops should wear personal safety equipment such as gloves, safety footwear and suitable work wear. The boards must be lifted. The decor sides should never be pushed against one another or dragged over one another.

## Processing

As described in chapter [storage and conditioning](#), ensure that the worktops are adequately conditioned before processing. The worktops must be conditioned for at least 24 hours under normal climatic conditions before processing. Only suitable machines and tools should be used for processing. Cutting, drilling and milling tools should always be selected in consultation with the tool manufacturers. Furthermore, only sharp tools should be used, as this is decisive for the machining result.

### Cutting

The worktops can be cut to size using standard woodworking equipment, e.g. panel saws, bench circular saws, hand-held circular saws or jigsaws and also CNC routers. Panel saws or bench circular saws are generally used to cut the worktops to size. A good cutting result depends on different factors including whether the decor side is facing upwards, saw blade projection, feed rate, tooth shape, tooth spacing, motor speed and cutting speed.

#### Example: Circular saw

- >> Cutting speed: approx. 40 to 60 m/sec
- >> Rotational speed: approx. 3,000 to 4,000 rpm
- >> Feed rate: approx. 10 to 20 m/min (manual feed)

With the exception of panel saws and CNC routers, all cutting involves manual feed. Due to the high-quality resins and UV lacquer used for the surface of the laminates, the tool wear is considerably greater than with conventional wood-based materials. The Compact Laminate Worktops in particular lead to increased tool wear due to their high density. We recommend that you use carbide metal-tipped or even diamond-tipped saw blades or router bits.

Use the following tooth shapes depending on the standard of finish you require (coarse or fine cut):




Figure 7: Examples of common saw blade tooth shapes

Use a cutting guide when working with a hand-held circular saw or jigsaw. Cutting must be from the reverse side of the board.

Saw type	Decor side	Application
<p><b>Panel or bench circular saws</b></p> <p>The worktop lies on the guide carriage and is guided towards the bench circular saw.</p> <p>Front edge towards the guide rail.</p>	facing upwards	
<p><b>Hand-held circular saws or jigsaws</b></p> <p>The hand-held circular saw is guided against the worktop.</p> <p>Front edge towards the operator.</p>	facing downwards	

Table 1: Cutting procedure

### Drilling

Before drilling, always ensure that the worktop is securely in place to prevent damage. HSS drill bits (high speed steel) are suitable for manual machines and carbide drill bits (hard metal) are recommended for machines with mechanical feed.

The following drill bit types are used depending on the required size of the hole (e.g. pilot hole, concealed hinges holes, etc.):




Figure 8: Examples of proven drill bit types

If fittings, Worktop Wall Profiles, etc. are to be attached to the worktop, the worktop must be pre-drilled in the area of the screw connection. The holes must be at least 0.5 mm larger than the screw diameter to avoid tension in the material – see figure 9.



Figure 9: Example of a 3,5 mm screw with pre-drilling

It is generally recommended to deburr the laminate drill holes. For example, a drill with integrated countersink can be used for this – see figure 8. When drilling with a hole saw, deburring is always necessary due to possible stress cracks. Routers are generally used for larger diameters.

## Cut-outs

Before processing, ensure that the worktop is supported securely so that the sawing, routing or drilling work is not likely to cause any damage. In particular, narrow board areas surrounding apertures can break or crack if the board is inappropriately handled during processing. The board cut-outs should also be secured so that they cannot break or fall out in an uncontrolled way and thereby cause injury to individuals or damage property.

The cut-outs edges should be radiused (minimum radius > 5 mm) as sharp edges have an adverse effect on the material and can lead to crack formation see figures 10 to 13. This applies particularly to the hob area where the frequent exposure to heat causes the laminate to dry out, thereby increasing shrinkage tension.

Always read through the instructions and use the assembly templates provided by the manufacturers.

The cut-outs should preferably be made using a portable hand router or CNC milling machine. When using jigsaws, the cut-out corners should be pre-drilled with an appropriate radius and the cut-out sawn out from radius to radius. You should cut from the underside of the board to prevent the laminate coating from ripping off. The edges should be finished by means of sandpaper, filing or manual top milling to eliminate cracks due to chipping. The same careful finishing should be considered when using "hole saws" for e.g. sockets – see section [Drilling](#).

Due to the high cutting pressure, a safe workpiece and tool control is particularly important. Drill bits for plastic are best suited for drilling Compact Laminate Worktops. All edges should be smooth, free of cracks and notches. Grooves and folds must also be chamfered to prevent notches. For installed components, sufficient space must be provided for expansion. For more detailed information and corresponding tool recommendations for the Compact Laminate Worktop, please refer to the [Processing instructions Compact Laminates](#)




Figure 10: Correct – Cut-out with radius




Figure 11: Incorrect – Square Cut-out




Figure 12: Correct – Recess with radius




Figure 13: Incorrect – Square recess

As a rule, worktops are effectively protected from moisture penetration by the laminate surface. Moisture and damp can still reach the core material, however, via unprotected edges such as cut-outs, butt joints, corner joints, rear edges, drill holes and screw holes. The necessary final sealing operations should always be carried out during the final assembly phase, especially with horizontal surfaces, such as worktops. For concealed cut edges, sealing profiles and cross-linking sealing compounds made of silicone rubber or polyurethane have proven their suitability. Compact Laminate Worktops, on the other hand, are resistant to moisture due to their construction, although the use of sealing compound is recommended. In addition to the optical seal, the sealing compound also prevents liquids from penetrating into the cabinet. When using sealants, a primer also has to be applied; either one that forms a film or a cleaning primer depending on the material.

You must follow the manufacturer's instructions carefully when using these materials.

Apply the sealant leaving no gaps or holes and then smooth over with water and detergent. Areas near joints should be masked off to prevent the surface from becoming dirty. Pipes or conduits must be centred so that a minimum clearance of 2 to 3 mm is maintained on all sides of the feed-through. Careful sealing is also required— see figure 14.




Figure 14: Sealing a pipe opening against moisture penetration

Cut edges can also be sealed using a two-part lacquer or two-part adhesive. For built-in parts such as mixer taps, sinks and hobs, the manufacturer supplies sealing rings, sealing profiles or sealing strips, which must always be installed in accordance with the manufacturer's instructions. The specially developed EGGER Sealing for Corner Joints is available for sealing joints that are created for worktop corner connections. The flexible seal prevents moisture and liquids from penetrating into the joint. Detailed information can be found in chapter [worktop joints and corner joints](#).

## Edging

Worktops should be edged with thermoplastic EGGER ABS Edging or EGGER decorative multilayer edging. For the manual application of decorative multilayer edging, normally PVAc glues or contact adhesives are used. The PVAc glue is applied evenly to the clean and dust-free chipboard edge using a paint brush. Then the Decorative Multilayer Edging is pressed on with an edge press, glue press clamp or screw clamp using a stiff block of wood for protection and ensuring that there is sufficient overhang of edging on both the face and the underside of the worktop. The setting time can be considerably reduced by using heating bars.

Please observe the information provided by the adhesive manufacturers.

Edge milling cutters, files, chisels or sharp block planes are used for the finishing of decorative multilayer edging. The cutting should always be with light pressure at an oblique angle against the edge (shear action). EGGER decorative multilayer and ABS edging are used for the protection and design of worktops. Exposure to moisture in unprotected areas of the edges and well as in the hob and sink cut outs will lead to swelling.

Further information on EGGER Edging can be found on our website [www.egger.com/edging](http://www.egger.com/edging).

The Compact Laminate Worktops, on the other hand, have a homogeneous, closed edge due to its construction. In addition, the worktops have chamfer millings on the longitudinal sides. If the panel dimensions are changed, the edges should preferably be milled after cutting. For an even more brilliant appearance of the edge quality, it is recommended to treat the compact laminate edge with oil. The oil offers additional protection against impurities and unwanted oxidation effects and thus guarantees a permanently perfect appearance.

Recommended edge oils:

- » Adler Linseed Oil Varnish 95901
- » Hesse Proterra Natural-Solid-Oil GE 11254
- » Adler Legno-Oil 50880ff
- » Rubio Oil Plus Pure (transparent)

## Assembly

Worktops have good dimensional stability. Climate changes cause the worktop to shrink or expand, which means that format changes must be taken into account. The format changes for the Compact Laminate Worktops are approximately half as large in the lengthwise direction as in the crosswise direction. Format changes have to be taken into account from the outset in design and processing. As a rule, an expansion play of 2.0 mm / m should be provided.

### Installation of sinks and hobs

Cut-outs for hobs or sinks must be produced according to the measurements and positioning details and/or using templates supplied by the manufacturer. The cut-out edges must be carefully protected against moisture according to the topics [Drilling](#) and [Cut-outs](#). Accompanying or integrated dry seals and fastening screws provided by the manufacturer must be used according to their assembly instruction – see figure 15.



Figure 15: Sink with dry seal



Figure 16: Hob with aluminium foil

Ensure correct centering and an adequate safety margin to the cut edge, particularly for hobs. As additional protection against heat absorption we recommend also fitting self-adhesive aluminium tape or a metal profile around the edges – see figure 16. The hob must not abut against the surface for safety reasons, as a temperature increase of up to 150 K is possible in the event of faulty operation. Further installation options are surface-flush mounting or undermount solution. For the flush-mounted version, the core board is milled up to the laminate and then a resin frame is cast below the laminate – see figure 17. The undermount sink solution can only be realized with a Compact Laminate Worktop – see figure 18.




Figure 17: Flush-mounted version




Figure 18: Undermount sink

As commercial sinks are generally mounted on worktops approx. 38 mm thick, a special solution is required for the thin worktop options (e.g. EGGER Compact Laminate Worktops). For this purpose, fixing strips are glued to the reverse of the cut-outs (Compact Laminate Worktops) to ensure easy installation – see figures 19.




Figure 19: Fixing strips glued

The worktop should not measure less than 50 mm at any one place. For ergonomic reasons, the distance between the hob area and an upright cupboard should not be less than 300 mm. Allow for the hob manufacturer's specified safety margin. The same distance is recommended for the gap between the sink and the hob – see figure 20.




Figure 20: Dimensioning for cut-outs

For safety reasons as much as for ergonomic reasons, kitchen designs should be discussed with a kitchen specialist and fitting carried out by a specialist company. Particularly electricity, gas and water supply connections must be carried out by trained specialists. In the region of corner connections, a minimum distance of 300 mm must be taken into account during planning – see figures 21 and 22.





Figure 21: Correct – Position of sink / hob

Figure 22: Incorrect – Position of sink / hob

Once the cut-out sections have been implemented in the worktops, any further transportation must be carried out while observing the utmost caution as to prevent “snapping at thin points”. Worktops should be carried upright because cut-outs and worktop can be damaged more easily if the boards are carried horizontally.

A standard construction can generally be used for conventional base units. In the construction of sink and/or cooker base units, the assembly of metal traverses has proven to be successful. The worktop is secured against possible bending by the metal traverse, as the worktops are weakened due to sink and/or hob cut-outs and the contact surface on the base units is minimized. Especially for thin worktops (e.g. EGGER Compact Laminate Worktops), the use of metal traverses is recommended. In addition to stabilization, the metal traverses are also used to secure the worktop or covers – see figure 23.



Figure 23: Metal-traverse for cut-outs

### Worktop joints and corner joints

In general, a worktop length of 4,100 mm means panel joints are avoided, whereas worktop corner joints are common. These should not be weakened by recesses or cut-outs such as for hobs or sinks – see figures 22 and 23. Corner joints on worktops are made by mitering on circular saws or routing using CNC routers and / or using special hand-held routers with the aid of templates – see figures 24 und 25.




Figure 24: Worktop corner joint




Figure 25: Worktop corner joint

Alternatively, metal connection profiles can be fitted – see figure 26.




Figure 26: Worktop corner joint with metal connection profile

Worktop joints and corner connections need to fit perfectly and be completely sealed, and not just for aesthetic reasons. They need to repel any moisture which can cause swelling of the chipboard. For this purpose, EGGER Sealing for Corner Joints was specially developed for sealing the joints (corner joints) of kitchen worktops. The flexible sealing prevents moisture and liquids from penetrating into the joint. It is resistant to detergents, water, fats, oils etc. and is available in four different colors. The content of the 10 g tube is enough for an average joint length of 600 mm – see figure 27.




Figure 27: Sealing of Worktop corner joint

Compact Laminate Worktops do not require sealing due to the homogeneous construction of the boards. The worktop has chamfer millings on the longitudinal sides. Additionally, when the transverse sides are also chamfered, the usual contour milling for corner joints is no longer necessary. The chamfer separates the two worktops from each other, which means that a conscious highlighting of the chamfer on the worktop front is achieved. This application with the chamfer joint is known and common in the field of stone worktops, for example – see figure 28.





Figure 28: Chamfer milling on Compact Laminate Worktops

The application of the sealing begins with the perforation of the membrane closure of the tube and the following unscrewing of the black application support – see figure 27. In the following, the application support is guided along the upper side of the worktop joint and the sealing compound is evenly pressed out of the tube. Immediately after applying the sealing, the worktops must be joined and screwed together. Any leaked residue should be removed directly with a suitable cleaning product – see figure 29.

For more detailed information and recommended colour combinations for the respective worktop decors, please refer to the technical leaflet [EGGER Sealing for Corner Connections](#).



- 1 EGGER Sealing for Corner Joints
- 2 Moulded spring (Biscuit)
- 3 Glue

Figure 29: Sealing of worktop corner joint

The individual worktops are attached using worktop connectors as well as fixing supports, so-called biscuits, and additional glue to strengthen the bond – see figures 29 and 30. Depending on the worktop selection, different worktop connectors are required. The EGGER Compact Laminate Worktops require the use of special EGGER Worktop Connectors due to their low material thickness. EGGER offers these as a set suitable for the 12 mm thick Compact Laminate Worktops – see figure 31. The compact worktop milling pocket for the 12 mm connector is milled to a depth of approx. 8 mm. – see figure 32.

For more detailed information please refer to the technical leaflet [EGGER Worktop Connectors](#).




Figure 30: Worktop Connectors




Figure 31: EGGER Worktop Connectors




Figure 32: Milling pocket EGGER Worktop Connector

The number of worktop connectors is dependent upon the width of the worktop. In general two connectors are used for widths up to  $\leq 799$  mm and three connectors are used for worktops with a width of  $\geq 800$  mm. Flush fitting worktop surfaces are achieved by always measuring the locations of the crescent shaped biscuit (moulded spring) slots from the top of the worktop surfaces and by ensuring a tight fit of the biscuits themselves.

The following production steps should be observed:

1. Remove any raised wood chips near the cut or milled edges with sand paper (grit 120).
2. Bevel the laminate slightly along the joint with a sanding sponge or sandpaper (grit 360).
3. Place the worktops on the aligned base units and check the joints and fitting holes for correct fit.
4. Apply glue, D3 quality, to the central and lower area of the joint.
5. Apply sealant (EGGER Sealing for Corner Joints) evenly and continuously to the top routed or cut edge as well as to the profile and long back edge. You should do this just before screwing the worktop connectors in place.
6. Join the worktops together, insert fittings and tighten screws slightly. Align the worktops horizontally using wedge or lever and vertically using a rubber hammer or clamps (protect with cushion blocks). Once aligned, tighten the worktop connectors hand-tight. When tightening, you must check that the two worktop surfaces remain aligned and the sealant emerges on all sides – see figure 29. Do not place any stress on the worktops while the sealant is hardening.
7. Remove excess sealant immediately. Clean the worktop surface using a suitable cleaning agent such as citrus cleaner or acetone. Caution: Acetone can affect the surface if left for a long period. We therefore recommend masking off the joint area with masking tape.

## Fastening and wall connection

Before sealing the long edge of the worktop against a wall, make sure that it is not just adequately supported, but is also joined to the sub-frame. Stresses can otherwise occur that will interfere with the sealing joint. For the Compact Laminate Worktop, screws with a slow thread are recommended as they achieve a better pull-out resistance. The worktop is usually fixed to the base units with screws using the base unit traverses – see figure 33. This conventional fastening is also possible with thin worktops such as the EGGER Compact Laminate Worktop. However, it must be noted that the contact surface of a thin worktop on the base unit traverses must be adjusted for base units  $> 600$  mm wide to prevent possible bending



Figure 33: Base unit traverse

When fitting, make sure that the worktop is not tilted towards the wall. This will result in water collecting at the joint area. Clean and degrease around the sealing area on both the worktop as well as the wall joint and pre-treat with a bonding agent depending on the sealing used. Even if using Worktop Wall Profiles, you need to seal the long back edge and all transverse edges which abut to a wall with sealing. It is particularly important for the Compact Laminate Worktop to ensure a minimum distance of 2 mm between the worktop and the wall and to seal it as described above – see figure 35. When attaching the fixing rail provided with Worktop Wall Profiles, ensure that the laminate is predrilled in the screw fastening area. The holes must be at least 1 mm larger than the screw diameter to prevent tension building up in the material – see figure 34. We also recommend protecting the inside of the screw hole with sealing before fixing the screw.




Figure 34: Predrilling for fastening




Figure 35: Sealing to the wall

For more detailed information, please refer to the technical leaflet [EGGER Worktop Wall Profiles](#) or processing instructions [EGGER Worktop Wall Profiles](#).

### Structural water-repelling measures

Worktops are particularly subject to steam and heat exposure near dishwashers and ovens. In addition to the UV lacquer seal and the seal you should also protect the reverse of the worktop by structural means. Self-adhesive aluminum foils generally provide reliable water vapor protection and are easy to handle – see figure 36. Appliance manufacturers supply aluminum repellent strips or protective cover plates, which you must use. This moisture-repellent strip or cover plate deflects and repels steam and heat – see figure 37.

Refer to the manufacturer's instructions carefully before assembling.




Figure 36: Self-adhesive aluminium foil




Figure 37: Cover plate

The mounting of the aluminum foil on the underside of the panel differs between models 300 and 100. For the “EGGER Postforming Worktops” (model 300), the aluminum foil should overlap the laminate on the underside by about 2 mm – see figure 38. For the “Square Edged Worktops” (model 100), the aluminum foil should be mounted so that it overlaps the ABS Edging by about 1 mm – see figure 39.




Figure 38: Postforming Worktop (MOD 300)




Figure 39: Square Edged Worktop (MOD 100)

## Maintenance and cleaning recommendations



Placing burning cigarettes on the laminate surface leads to surface damage.  
Always use an ashtray.



Laminate surfaces should not be used as a cutting surface as this can also leave cutting marks on highly resistant laminate surfaces. Always use a chopping board.



Placing hot cooking utensils such as saucepans and frying pans directly from the hob or oven onto the laminate surface should be avoided, as, depending on the heat exposure, a change in the gloss appearance or damage to the surface can arise. Always use heat resistant mats.



To prevent the worktop from swelling, e.g. in areas of cut-outs and joints, liquids should be wiped up quickly. Do not open dishwashers, washing machines and dryers until they have cooled down.



Spilled liquids should always be cleaned up immediately, especially in the areas around cut-outs and joints as prolonged exposure to some substances may cause a change in the gloss appearance of the laminate surface.

For detailed information, please refer to the leaflet [Cleaning and care recommendations for EGGER product surfaces](#).

## Additional documents / Product information

You will find further information in the following documents:

- » [Technical data sheet „EGGER Postforming Worktops“](#)
- » [Technical data sheet „EGGER Feelwood Square Edged Worktops“](#)
- » [Technical data sheet „EGGER PerfectSense Premium Square Edged Worktops Matt“](#)
- » [Technical data sheet „EGGER Compact Laminate Worktops“](#)
- » [Technical leaflet „Cleaning and care recommendations for EGGER product surfaces“](#)
- » [Technical leaflet „Laminate – Resistance to chemicals“](#)
- » [Technical leaflet „EGGER Worktop Connectors“](#)
- » [Technical leaflet „EGGER Sealing for Corner Joints“](#)
- » [Technical leaflet „EGGER Worktop Wall Profiles“](#)
- » [Processing instructions „EGGER Worktop Wall Profiles“](#)
- » [Processing instructions „EGGER Compact Laminates“](#)
- » [Environmental and Health data sheet „EGGER Postforming Worktops“](#)

### Provisional note:

This processing instruction have been carefully drawn up to the best of our knowledge. The information provided is based on practical experience, in-house testing and reflects our current level of knowledge. It is intended for information only and does not constitute a guarantee in terms of product properties or its suitability for specific applications. We accept no liability for any mistakes, errors in standards, or printing errors. In addition, technical modifications may result from the continuous development of EGGER Worktops, as well as from changes to standards and public law documents. The contents of the processing instruction should therefore not be considered as instructions for use or as legally binding. Our General Terms and Conditions apply.